

Use the drawing below as an example for measuring your existing fasteners. If you have more fasteners than shown than just add them to the drawing. We need accurate measurements to ensure that our pattern will work. Repeat the process for all of the windows that are getting covers.

